


Selecting A Ring Tone

1. On your phone, navigate to Menu -> Basic-> Sound-> Ring Tones-> Common
2. Select a desired ring tone.



3. (Optional.) Press the Volume key to adjust the ringer volume.
4. Press Save.